

TRH 12

RELATIVE HUMIDITY AND TEMPERATURE PROBE



OPERATING INSTRUCTIONS Vr. 01 (ENG) - cod.: ISTR 05833

TECNOLOGIC S.p.A.

VIA INDIPENDENZA 56 27029 VIGEVANO (PV) ITALY TEL.: +39 0381 69871 FAX: +39 0381 698730 internet : http://www.tecnologic.it e-mail: info@tecnologic.it

PREVIOUS STATEMENT

correct installation and the instructions for the use and the it has to be reminded that the plant has to be equipped with maintenance of the product; we recommend, therefore, to read additional electromechanical devices in order to grant the safety. carefully the following instructions.

The maximum care has been used in the realisation of this 2.2 - MECHANICAL MOUNTING document, anyway TECNOLOGIC S.p.A. does not assume any The instrument, into case 80 x 80 mm , is designed for wall responsibility deriving from the use of itself.

The same consideration has to be done for each person or Company involved in the creation of this manual.

S.p.A. which forbids any reproduction and divulgation, although and polluting gases (see Concentration Maximum Pollutant in the partial, if not expressly authorised.

TECNOLOGIC S.p.A. reserves the right to execute aesthetically and functional modifications, at any moment and without any notice.

INDEX

- DESCRIPTION 1 GENERAL DESCRIPTION 1.1
- 1.2 PROBE DESCRIPTION
- 2 INSTALLATION AND USE ADVICES
- USE ALLOWED 2.1
- 2.2 MECHANICAL MOUNTING
- 2.3 ELECTRICAL CONNECTIONS
- ELECTRICAL CONNECTION DRAWINGS 2.4
- 3 **OPERATING MODE**
- 4 TROUBLES, MAINTENANCE, WARRANTY
- 4.1 ERRORS
- 4.2 CLEANING
- WARRANTY AND REPAIRS 4.3
- 5 **TECHNICAL DATA**
- 5.1 **ELECTRICAL DATA**
- 5.2 MECHANICAL DATA
- MECHANICAL DIMENSIONS AND FIXING DEVICE 5.3
- FUNCTIONAL DATA 5.4

1 - DESCRIPTION

1.1 - GENERAL DESCRIPTION

TRH 12 is a relative humidity (capacitive type) and temperature (RTD Pt100 type) probe with normalized outputs current signal 0 ... 20 mA.

1.2 - PROBE DESCRIPTION



1 - Sensors protective cap

2 - Terminal block

3 - Cable gland M20x1,5

2 - INSTALLATION AND USE ADVICES

2.1 - USE ALLOWED

The instrument has been projected as measure transductor.

It has to be reminded that the user has to take care that the electromagnetic rules are being respected also after the instrument installing, eventually using

proper filters.

Whenever a failure or a bad functioning of the instrument may In this manual are contained all the necessary information for a cause dangerous situations or damage to people, things or animals

mounting.

Install the instrument as far as possible from electromagnetic sources as motors, power relay, relays, electrovalves, etc.

The herewith issue is an exclusive property of TECNOLOGIC Avoid to place the probe into places where are present corrosive Technical Data) and to do so that the probe are installed in ventilated position.

> Should be necessary to remove the protective cap, do not cause any mechanical stress to the sensors and absolutely avoid touching the umidity sensor.

2.3 - ELECTRICAL CONNECTIONS

To access the terminal block remove the cover by unsrewing the provided with a current input 0 ... 20 mA type. two screws on it.

Avoid touching any electronic components and carry out the and upper input limits. electrical wiring connecting one wire only for each terminal, These limits are the corrisponding value to 0 mA (lower limit or according to the following diagrams, checking that the power supply beginning of scale) and 20 mA (upper limit or ending of scale) which is the same as indicated on the instrument.

grip of the same and of the cover box to obtain the declared setting mode of these limits. protection degree.

Check then if the measure instrument is equipped with a voltage 9...30 VDC able to supply at least 50 mA, otherwise Upper limit umidity measure (20 mA) : 100 output connecting the probe with an external voltage supply 9...30 VDC <u>Lower limit temperature measure (0 mA)</u>: -30 (°C) or -22 (°F) able to supply the necessary current as previously described and <u>Upper limit temperature measure (20 mA)</u>: 70 (°C) or 158 (°F) connecting it following the wiring diagrams.

It's strongly recommended to use cables with proper insulation, according to the working voltages and temperatures.

Furthermore, the cable of the probe has to be kept separate from line voltage wiring in order to avoid electromagnetic noises infiltration.

If the input cable of the probe is screened, it advisable to connect it on the ground with one side only.

Tecnologic S.p.A. and its legal representatives are not responsible for any eventual damages to people, things or 4.1 - MEASURE ERRORS animals deriving from the instrument violation, not proper or Umidity reading errors can occur if settling time is too short, or be wrong use or in any case not in accordance with the instrument caused by steam, sprayed water, air drafts, direct exposure to features.

2.4 - ELECTRICAL CONNECTION DRAWING

Wiring diagram with instrument supply :



Wiring diagram with external supply :



3 - OPERATING MODE

The instruments to which the probe has to be connected has to be

To have a correct measure indication is necessary to set the lower

have to be displayed.

Use the cable gland to make the cable exit and check the correct See on the operating instructions of the measure instrument the

The set values for TRH 12 probe are:

Lower limit umidity measure (0 mA) : 0

It's possible to use instruments with input 4 ...20 mA, in this case the limits to set will be:

Lower limit umidity measure (4 mA) : 20

Upper limit umidity measure (20 mA) : 100

Lower limit temperature measure (4 mA) : -10 (°C) or 14 (°F)

Upper limit temperature measure (20 mA) : 70 (°C) or 158 (°F)

4 - PROBLEMS, MAINTENANCE AND WARRANTY

sunlight, or presence of condesate on the sensor.

To obtain accurate measurements the sensor should be left to settle in the existing atmosphere for some time.

To reduced the possibility of condesation on the humidity sensor place the probe in ventilated position and where there is not a quick and elevation variation of temperature (from cold to warm)

4.2 - CLEANING

It's raccomanded to clean the box only with a cloth welted with water or with a detergent neither abrasive nor containing solvents.

Should be necessary to remove the protective cap, do not cause any mechanical stress to the sensors and absolutely avoid touching the umidity sensor.

4.3 - WARRANTY AND REPAIRS

The instrument is under warranty against construction vices or defected material, noticed within 12 months from delivery date.

The warranty is limited to the repairs or to the substitution of the instrument.

The eventual violation of the instrument or the wrong use and installation of the product means the automatic decay of the warranty

In case of defected instrument, noticed in warranty period or out of warranty, do contact our sales department to obtain the shipment authorisation.

The defected product must be shipped to TECNOLOGIC with the detailed description of the failures found and without any fees or charge for Tecnologic, safe different agreements.

5 - TECHNICAL DATA

5.1 - ELECTRICAL DATA

Power supply: 9 ... 30 VDC Power consumption: 50 mA MAX Humidity sensor type: Capacitive Temperature sensor type: RTD Pt100 (class B) External load: 250 Ω MAX Humidity output signal : 0...20 mA (0 ...100 %RH) Temperature output signal : 0...20 mA (-30 ...70 °C) Protection class against electric shock: Class III

5.2 - MECHANICAL DATA

Housing: plastic Dimensions: 80 x 80 mm, depth 52 mm Weight: 130 g approx. Mounting: Wall mounting

Connections: 2,5 mm² screw terminal block Recommended connection cable: 4x0,5 or 4x 75 mm² Box protection : IP 65 Air filter: Polyethylene Operating temperature : -30 ... 70 °C Operating humidity: 0 ... 100 RH% Storage temperature: -30 ... 80 °C Maximum workplace pollutant concentration: 1000 ppm Acetone (CH3COCH3) 2400 mg/m³ 18 mg/m³ Ammonia (NH3) 25 ppm Petrol 300 ppm 1200 mg/m³ 1,5 mg/m³ Chlorine (Cl2) 1 ppm Acetic Acid (CH3COOH) 10 ppm 25 mg/m³ Ethyl Acetate (CH3COOC2H5) 400 ppm 1400 mg/m³ Ethanol (C2H5OH) 1000 ppm 1900 mg/m³ Ethylene Glycol (HOCH2CH2OH) 100 ppm 260 mg/m³ Formaldehyde (HCHO) 1 ppm 1,2 mg/m³ 980 mg/m³ Isopropanol ((CH3)2CHOH) 400 ppm 2-Butanone (C2H5COCH3) 200 ppm 590 mg/m³ Hydrochloric Acid (HCI) 5 ppm 7 mg/m^3 13 mg/m³ Sulphur Dioxide (SO2) 5 ppm 15 mg/m³ Hydrogen Sulphide (H2S) 10 ppm Nitrogen Oxides (NOx) 5 ppm 9 mg/m^3 380 mg/m³ Toluene/Xylene (C6H5CH3) 100 ppm

5.3 - MECHANICAL DIMENSIONS AND FIXING DEVICE [mm]



5.4 - FUNCTIONAL DATA

Humidity measurement range: 0 ... 100 %RH (0...20 mA) Temperature measurement range: -30 ... 70 °C (0...20 mA) <u>Humidity overall accuracy :</u> +/- 1,5 % (10...95%RH), +/- 2 % (0...10 / 95...100 %RH) ; (without pollutant presence, at 23 °C and with an air speed of 3 m/s) <u>Additional error with pollutant presence:</u> +/- 2 %RH <u>Temperature overall accuracy :</u> +/- 0,9 % <u>Response time :</u> 30 sec. to reach a 63 % of an humidity change (at

23 °C and with an air speed of 3 m/s)

Recovery time after saturation: 90 sec. approx.

Maximum air speed: 20 m/s

Temperature compensation: By Pt100 probe

<u>Compliance:</u> ECC directive EMC 2004/108/CE (EN 61326), ECC directive LV 2006/95/CE (Instrument operating under 50 VAC and 75 VDC)